

ROCKN

ORBIT 2.0 SERIES

TRUE WIRELESS STEREO EARPHONES



INSTRUCTION MANUAL

Please read these instructions carefully and retain for future reference.



RK-1113-BK

HIGHLIGHTS

- True Wireless Earphones
- Hands-free Calling / Walk and Talk
- True Stereo Sound
- 10 mm Drivers
- Portable Charging Case Gives 12-Hour Playtime


PACKAGE CONTENTS

- Rocka Orbit 2.0 Series True Wireless Stereo Earphones
- Charging Case
- 3 x Earbud Cap Sizes
- USB Charging Cable
- Instruction Manual

SPECIFICATIONS

- Bluetooth
 - Version: 5.0
 - Chipset: JL 6936A
 - Profiles: A2DP / AVRCP / HFP
 - Operating Distance: 10 m
- Charging Case:
 - Battery: 400 mAh
 - Number of Recharges: 3
 - Charging Time: 1 ~ 2 Hours
 - Charge Input / Power Supply: 5 V DC
- Earphones:
 - Battery: 50 mAh per Earphone
 - Charging Time: 1 ~ 2 Hours
 - Playback Time: 2 ~ 4 Hours
 - Sensitivity: 102 dB
 - Driver: 10 mm
 - Impedance: 32 Ω
 - Frequency Response: 20 Hz ~ 20 kHz

IDENTIFYING PARTS



1. Magnetic Charging Pogo Pins
2. Charging Case
3. Charging Case LED Light Indicator
4. **ROCKY** Multi-Function Button
5. Microphone
6. Earphone LED Light Indicator

INSTRUCTIONS FOR USE

CHARGING THE CASE

Please ensure that the battery is fully charged before using the device for the first time.

- Connect the provided USB Charge Cable to the DC 5 V charging slot on the Charging Case, connect the other end of the USB to a wall charger or an available USB port on a compatible device.
- The Blue LED Indicator Light will pulse to indicate that charging has begun.
- The LED Indicator will pulse repeatedly to indicate that the battery is flat.

Note: Once fully charged, the Blue LED will become a solid light.

CHARGING THE EARPHONES

Please ensure that the battery is fully charged before using the device for the first time.

- Place the earphones into the Charging Case. A Red Light inside the earphone will turn on when the charging has begun. The Red Light will turn off when the charging is complete.

Note:

- Charge time is approximately 1 ~ 2 hours. Earphones cannot be used while charging.
- When the battery level is low and only 5 minutes of playtime is left, you will hear a warning voice message. The message is repeated every 20 seconds.
- The earphones will turn off when inserted into the Charging Case, even if they are powered ON before charging.

SWITCHING THE EARPHONES ON

- To switch on the device, press and hold the **ROCKN** Multi-function Button for about 3 seconds until the blue and red LED lights turn on and start flashing.
- To switch off the device, press and hold the **ROCKN** Multi-function Button for about 3 seconds until the LED light turns off, you will then hear a voice prompt stating that the earphones have been powered off.

Note:The earphones would need to be turned on individually.

PAIRING WITH EACH OTHER

Turn on both earphones at the same time. After powering on the earphones, wait a couple of seconds and you will hear the earphones pair to each other.



Note: This can be done separately to use earphones individually.

PAIRING WITH BLUETOOTH DEVICES

Your earphones must be paired to a Bluetooth device before they can be used. It is only necessary to pair your earphones once with each device.

1. Ensure that your device's Bluetooth is on. Search for the device "Orbit 2.0". Confirm pairing by selecting the device from the list.
2. When successfully paired, the earphones will beep.
3. The device is now ready to make / receive calls and playback music.

MAKING AND RECEIVING CALLS

- When the earphones are paired to your smartphone, you will be able to make or receive calls using the built-in microphone.
- When receiving a call, press the  Multi-function Button on the earphones to answer calls. Press the  Multi-function Button 3 times on the earphones to reject incoming calls.

LOCATING THE BLUETOOTH MENU

iPhone, iPad and iPod Touch

1. On your device, go to Settings.
2. Select Bluetooth. If Bluetooth is not on, turn it on.
3. The iPhone / iPad / iPod will automatically search for new devices.

Android Phones and Tablets

1. On your device, go to the Settings Menu.
2. Select Bluetooth (on older Android devices Bluetooth is found in the Wireless & Networks Menu). If Bluetooth is not on, turn it on.
3. Select “Search for Devices” if your phone or tablet does not automatically search for new devices.





Note: If you are unsure on how to access your Bluetooth Menu on your device, please refer to your device’s instruction manual.

CONTROLS

Audio Controls

Function	Operation
Play or Pause Track	Short press the  Multi-function Button

Phone Calls

Function	Operation
Incoming Call – Answer	Short press the  Multi-function Button
Incoming Call – Reject	Triple press the  Multi-function Button
Call in Progress – End Call	Short press the  Multi-function Button
Call – Last Dialed Number	Double press the  Multi-function Button

Note: All calls will be heard on the left earphone.

TROUBLESHOOTING

- 1. My mobile phone cannot find any new Bluetooth devices?**
 - Ensure the Device has entered the pairing mode.
 - Ensure the Device is within effective working range.
- 2. Bluetooth device cannot pair up?**
 - Ensure your mobile phone allows new connections and has not reached the maximum number of allowed devices.
- 3. The Device does not play music or answer calls when it is connected to a Bluetooth mobile phone?**
 - Ensure your mobile phone supports A2DP and HSF (Hands-free) profiles.
 - Ensure your mobile phone is within effective working range.
- 4. When paired with my computer, Windows asks for a new driver. Can you supply this?**
 - We recommend you find compatible drivers for your computer online.
- 5. Why can I not remotely control the pause, play function when music is playing?**
 - This feature needs the Bluetooth device paired with the earphones to support AVRCP (Audio / Video Remote Control Profile). Please ensure your device supports this.

SAFETY PRECAUTIONS

- This product is not intended for commercial use and has been tested for household use only.
- This product is not intended for use by small children, or persons with diminished mental capabilities. Ensure that the use of this product is monitored by a guardian or parent.
- Never use your earphones near water or in areas where it can come into contact with water. Never handle the earphones if they have been dropped into water or any other liquid. If the product comes into contact with water while charging, this is a safety hazard.
- Do not operate the product after it malfunctions, has been dropped or damaged in any way.
- **WARNING:** Always keep optional accessories, small parts and packaging out of the reach of babies and small children, as these items may be a choking hazard.
- **DO NOT** overcharge your Rocka Orbit 2.0 Series True Wireless Stereo Earphones as doing so will shorten the lifespan of the built-in battery and could cause your device to overheat.
- **CAUTION:** Do not disassemble the battery or dispose of it in a fire.
- **CAUTION:** Should your battery show signs of overheating, smoke or fumes being emitted during charging, remove the charging cable immediately.

CLEANING AND CARE INSTRUCTIONS

- **Before Cleaning:** Ensure that your Rocka Orbit 2.0 Series True Wireless Stereo Earphones are turned off before cleaning or maintaining them.
- **Cleaning:** Wipe down the surface of your Rocka Orbit 2.0 Series True Wireless Stereo Earphones using a soft, slightly damp cloth.
- Do not use any harsh or abrasive cleaning chemicals or materials on your Rocka Orbit 2.0 Series True Wireless Stereo Earphones as doing so may damage or scratch the surface finish.
Do not expose your Rocka Orbit 2.0 Series True Wireless Stereo Earphones to direct sunlight or high temperatures for extended periods of time.
- Do not store in temperatures over 60°C.

ENVIRONMENTALLY FRIENDLY DISPOSAL



Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

DISCLAIMER

All product and company names are trademarks™ or registered® trademarks of their respective holders. Use of them does not imply any affiliation with or endorsement by them.

WARRANTY

These Rocka 2.0 Earphones come with a standard 12-month limited warranty against manufacturing defects and faults. Should your product be unboxed with any faulty parts, poor finishing or visible damage, or fail to perform due to a manufacturing defect or poor workmanship, please return it with your proof of purchase (till slip or invoice) to the store of purchase for an exchange, or repair, depending on the store's returns policy.

This warranty commences from the date of purchase.

Kindly retain your proof of purchase as well as the packaging for your warranty period.

NOTE:

The warranty does not apply to a product that:

1. Has failed due to excessive wear and tear beyond what is considered to be reasonable.
2. Has been misused or neglected.
3. Has been damaged accidentally or by acts of God including fire and flooding.
4. Has been used or operated contrary to operating or maintenance instructions outlined in this manual.

The Store of Purchase / Seller cannot accept any returned products that have not been returned in accordance to this warranty or which does not follow their own Returns Policy. Please refer to the Store of Purchase / Sellers Returns Policy for details.

Should you require any further assistance, please contact the store of purchase.