

ROCKN

ZETHE SERIES

BLUETOOTH HEADPHONE DESIGNED BY ZETHE



INSTRUCTION MANUAL

Please read these instructions carefully and retain for future reference.



RK-2102-BK

HIGHLIGHTS

- Bluetooth Wireless
- 7 Hours Playtime
- Hands-Free Calling
- FM Radio
- Micro SD Card Reader
- Aux Mode


PACKAGE CONTENTS






- Rocka Zethe Bluetooth Wireless Headphones
- USB Charging Cable
- Instruction Manual
- Aux Cable

SPECIFICATIONS

- Bluetooth Version : V 5.0
 - Chipset : JL
 - Range : 10 m / 33 ft
 - Profiles : A2DP / AVCTP / AVDTP / AVRCP
- Bluetooth Distance : 10 m
- Impedance : 32 Ω
- Frequency Range : 20 Hz ~ 20 kHz
- Sensitivity : 105 dB
- Battery : 250 mAh
- Power Requirement : 5 V DC
- Driver Size : 40 mm
- Charging Time : 1 Hour
- Playtime : 5 ~ 7 Hours

IDENTIFYING PARTS



1. Headband Size Adjuster
2. LED Indicator
3. Micro SD Card Slot
4. Aux Input
5. Micro USB Port
6. Handband Cushion
7. Hinge for Folding
8. Earcup
9.  Call / Answer Button
10.  FM/MP3 Mode Button
11.  Back / Volume Down
12.  Volume Up / Next
13.  Power / Play / Pause
14. Microphone

INSTRUCTIONS FOR USE:



CHARGING THE HEADPHONES

Your Rocka Zethe Headphones come with a partially charged battery, it is recommended that you fully charge your headphones before first use.

1. Connect the Charging Cable to the Micro USB Charging Port and either a PC or a dedicated USB Charger.
2. While charging, the Red Light will turn on and turn off once the unit is fully charged.

NOTE: On average your Rocka Zethe Headphones take about 60 minutes to charge.

SWITCHING ON / OFF THE HEADPHONES

1. To switch on the device, press and hold the  Power / Play / Pause Button for about 3 seconds until the Blue LED Indicator Light flashes.
2. To switch off the device, press and hold the  Power / Play / Pause Button for about 4 seconds until the Blue LED Light turns off.

PAIRING WITH BLUETOOTH DEVICES

Your Rocka Zethe Headphones must be paired to a Bluetooth device before they can be used. It is only necessary to pair your headphones once with each device.

Please switch on your Rocka Zethe Headphones before pairing them to your device.

1. Open the Bluetooth Menu on the device you wish to pair (see “Locating the Bluetooth Menu” for more details). Some devices require you to select “Search for Devices” or “Add New Device” in order to create a Bluetooth pairing.
2. Wait until you see “Rocka Zethe” on your device screen.
3. Select “Rocka Zethe” on your device and follow any further prompts to pair. Once pairing is complete and a connection is established, the headphone will sound with a short beep to indicate a successful connection and the LED Indicator will flash at a slower rate.

LOCATING THE BLUETOOTH MENU

iPhone, iPad, and iPod Touch

- a) On your device, go to Settings.
- b) Select Bluetooth. If Bluetooth is not on, turn it on.
- c) The iPhone / iPad / iPod will automatically search for new devices.

Android™ Phones and Tablets:

- a) On your device, go to the Settings Menu.
- b) Select Bluetooth (on older Android devices Bluetooth is found in the Wireless & Networks Menu). If Bluetooth is not on, turn it on.
- c) Select "Search for Devices" if your phone or tablet does not automatically search for new devices.

CONNECTING WITH PAIRED DEVICES

Once the headphones are turned on, they will automatically connect with the last paired Bluetooth device that is on and within range. If the headphones do not connect automatically, open the Bluetooth Menu on your device and select "Rocka Zethe" from the Bluetooth device list.

LED INDICATOR

In Bluetooth Mode, the Blue / Green Light will flash while the device is connecting. A Blue Light will flash slowly once the connection is established. In MP3 Mode, the Green Light will slowly flash while playing. In FM Mode, the Green Light will stay on and flash while you are scanning for radio stations. While charging, the Red Light will turn on and turn off once the unit is fully charged.

CONTROLS





1. Volume Controls

Function	Operation	Notes
Increase Volume	Long press the V+ / ►► Next Track / Volume Up Button	When the volume reaches the minimum or maximum level, the headphones will produce a short tone.
Decrease Volume	Long press the ◀◀ / V- Previous Track / Volume Down Button	

2. Audio Controls

Function	Operation
Play or Pause Track	Short press the ⏵ / ►► Multifunction Button
Next Track	Short press the V+ / ►► Next Track / Volume Up Button
Previous Track	Short press the ◀◀ / V- Previous Track / Volume Down Button
Stop	Short press the ⏵ / ►► Multifunction Button

3. Controlling Phone Calls

Function	Operation	
Incoming Call	Answer Call	Press the  Call Button once
	Reject Call	Long press the  Call Button twice in rapid succession or use your mobile phone to reject the call.
Call in Progress	End Call	Short press the  Call Button once or use your mobile phone to end the call.
Standby	Redial	While in standby mode, double press the  Call Button and the headphones will redial the last number dialed.

4. FM Radio

Function	Operation
Enter FM Mode	Long press the FM/MP3 Mode Button to cycle to FM Mode
Auto-Scan	Short press the ⏻/▶ Power / Play / Pause to auto-scan stations
Fine Tune	Short Press V+ / ▶▶ Volume Up / Next Button to skip a station and continue searching, or short press the ◀◀ / V- Back / Volume Down to return to a station.

SAFETY PRECAUTIONS

- The product should only be used with the parts provided by the manufacturer.
- This product is intended for indoor use only.
- Never use your Rocka Zethe Headphones near water or in areas where they can come into contact with water. Never handle the Rocka Zethe Headphones if they have been dropped in water or any other liquid. If the product comes into contact with water while still plugged in, this is a safety hazard.
- Always make sure your hands are dry before touching the USB Cable or power connections.
- Do not operate the product with a damaged cable, or after it malfunctions, has been dropped or damaged in any manner.
- The Rocka Zethe Headphones are intended for personal use only. Commercial use invalidates the warranty and the supplier cannot be held responsible for injury or damage caused when using the device for any other purpose than that which it was intended for.
- The Rocka Zethe Headphones are not intended for use by children, or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the device by a person responsible for their safety. Extreme caution must be exercised.
- Children should be supervised to ensure that they do not play with the Rocka Zethe Headphones. Packaging must never be left within reach of children, since it is potentially dangerous

CLEANING AND CARING INSTRUCTIONS

- **Before Cleaning:** Ensure that your Rocka Zethe Headphones are not charging before cleaning or maintaining them.
- **Cleaning:** Wipe down the surface of your Rocka Zethe Headphones using a soft, slightly damp cloth.
- Do not use any harsh or abrasive cleaning chemicals or materials on your Rocka Zethe Headphones as doing so may damage or scratch the surface finish.
- Do not expose your Rocka Zethe Headphones to direct sunlight or high temperatures for extended periods of time.
- Do not store in temperatures over 140 °F (60 °C).

TROUBLESHOOTING

1. My mobile phone cannot find any new Bluetooth devices?

- a. Ensure the device has entered the pairing mode.
- b. Ensure the device is within effective working range.

2. The Bluetooth device cannot pair up?

Ensure your mobile phone allows new connections and has not reached the maximum number of allowed devices.

3. The device does not play music or answer calls when it is connected to a Bluetooth mobile phone.

- a. Ensure your mobile phone supports A2DP and HSF (Hands-free) profiles.
- b. Ensure your mobile phone is within effective working range.

4. When paired with my computer, Windows asks for a new driver. Can you supply this?

We recommend you find compatible drivers for your computer online.

5. Why can I not remotely control the pause, play function when music is playing?

This feature needs the Bluetooth device paired with the headphones to support AVRCP (Audio / Video Remote Control Profile). Please ensure your device supports this.

ENVIRONMENTALLY FRIENDLY DISPOSAL



Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

DISCLAIMER

All products and company names are trademarks™ or registered® trademarks of their respective holders. Use of them does not imply any affiliation with or endorsement by them.

WARRANTY

These Rocka Zethe Headphones come with a standard 12-month limited warranty against manufacturing defects and faults. Should your product be unboxed with any faulty parts, poor finishing or visible damage, or fail to perform due to a manufacturing defect or poor workmanship, please return it with your proof of purchase (till slip or invoice) to the store of purchase for an exchange or repair, depending on the store's returns policy.

This warranty commences from the date of purchase.

Kindly retain your proof of purchase as well as the packaging for your warranty period.

NOTE:

The Warranty does not apply to a product that:

- a.) Has failed due to excessive wear and tear beyond what is considered to be reasonable.
- b.) Has been misused or neglected.
- c.) Has been damaged accidentally or by Force Majeure including fire and flooding.
- d.) Has been used or operated contrary to operating or maintenance instructions outlined in this manual.

The Store of Purchase / Seller cannot accept any returned products that have not been returned in accordance to this warranty or which does not follow their own Returns Policy. Please refer to the Store of Purchase / Sellers Returns Policy for details.

Should you require any further assistance or have any questions on your warranty, please contact the store of purchase.